


# TRON


## Multi-functional Power Bank 20000mAh



User Manual

**TR68**

### PRODUCT DIAGRAM



### Product Parameters

Item No.: PS-B004WA	Material: Fireproof ABS+PC
Battery: 20000mAh@3.85V 77Wh	Type-C Output: DC 5V-12V PD 20W Max
AC Input: 100~240V AC 50Hz/60Hz 0.5A(20W Max)	Lightning Cable Output: DC 5V~2.4A Max
Type-C Input: DC 5V-12V PD 18W Max	Type-C Cable Output: DC 5V-12V PD 20W Max
USB-A Output: DC 5V~3A,9V~2A,12V~1.5A 18W Max	Wireless Output: 15W Max
Sharing output: 5V~3A	Adaptor mode: 5V~3A 15 Max
Size: 132 X 73 X 32.5mm	Net Weight: 400g

### CHARGING & RECHARGING

Using the Power Bank

Please select your charging method from below and connect to a device.

The device will automatically begin to charge.

1. Built-in Cables
2. USB-A Port
3. Type-C Port

### Using the Wall Charger

1. Pull out the Prongs and connect to a wall outlet.
2. Plug a cable into the the USB or Type-C charging port and into a device.

### Checking the Battery Level

1. Quick press and the current percentage level will display on the digital screen.
2. Double click the power button or in standby for about 30 seconds, the display and power will be turned off automatically.

### Recharging the Multi-functional Power Bank

There are two ways to charge the internal battery:

1. Use the Wall Plug & and an AC Outlet
2. Use the Type-C to USB Cable and a Power Adapter.

### Recharging Time(From 0%):

1. Using Wall Charger: 5-6 Hours
2. Using Type -C Port with a 20W Wall Adapter: 5-6 Hours

### WHAT' S INCLUDED

- 1 x Multi-function Power Bank
- 1 x Detachable Carrying Strap
- 1 x AU Adapter Plug
- 1 x EU Adapter Plug
- 1 x UK Adapter Plug

### WARNING

- The power bank is NOT a toy and should be kept away from children.
- Please do NOT use the power bank in direct sunlight or extreme heat for extended periods of time.
- Please do NOT submerge the power bank in water.
- Please do NOT leave the power bank near the fire.
- Please do NOT subject the power bank to harsh chemicals.
- Please do NOT use the power bank if it has been damaged and/or modified.
- Please do NOT insert any foreign objects into the openings or port of the power bank.
- Please do NOT attempt to disassemble, repair, or open the power bank in any way.



**Note:** Warning Please follow the above safety instructions otherwise it will cause fire, electric shock, damage or other injuries.